

## Product Information 01-2016

### Change info regarding USB option for AMI-Transmitter



With introduction of the new mainboard (V2.5) for AMI Transmitters later this year and also the new specific mainboard for AMI Inspector (V2) the USB option has been modified.

Some features of the new USB Option are:

- Can carry the new 3<sup>rd</sup> Signal Output (0/4-20mA), A-81.420.050.
- New flash disc with less power consumption for the new AMI Inspector (V2)

Important Incompatibility note:

- Use of the previous USB Option (V1) on a mainboard V2.5 or AMI Akku board will/can destroy all electronic modules (the mainboard, the microcon, the PeriClip pump, fotometers, etc...) which communicate with I2C-Bus.
- Therefore the new USB Option (V2) has a different ordering number to separate the two versions.

A-81.420.040 AMI UBS Option, V1	A-81.420.042 AMI UBS Option, V2
	
<ul style="list-style-type: none"> <li>- Compatible to AMI Mainboard V2.4 or lower only!</li> <li>- Compatible to AMI Inspector V1 only</li> </ul>	<ul style="list-style-type: none"> <li>- Compatible to AMI Mainboard V2.5 or lower</li> <li>- Compatible to AMI Inspector V1 &amp; V2</li> </ul>