

Flow Cell M-Flow 10-3PG

Data sheet no. DenA83416330

General-purpose flow cell for measurements with pH, redox and ion-selective electrodes in water.

Features

- For installation of one or two electrodes and a temperature sensor with PG-13.5 thread.
- Suitable for electrodes with 12 mm diameter and a maximum shaft length of 120 mm.
- Removable sample vessel for easy sensor cleaning and calibration.
- Optional spray nozzle for sensor cleaning.
- Flow cell made of PVC and sample vessel made of PMMA.
- Can be mounted on an optional PVC panel together with Swansensor U-Flow.

Scope of delivery

- Flow cell M-Flow 10-3PG
- Mounting parts (three M5 screws)
- Two PG13.5 blind plugs

Sample conditions



Operating temperature: max. 50 °C
Operating pressure: max. 1 bar
Sample flow: 3 to 15 L/h
Pressure and temperature specifications apply to the flow cell without sensors.

Process connections

Inlet and outlet: Hose nozzle for 10 mm tube

Suitable transmitters

Use with SWAN pH/Redox, Dual pH/Redox and ISE Universal transmitters.



Flow cell M-Flow 10-3PG with sensors and spray nozzle

Order numbers: Flow cell M-Flow 10-3PG		A-83.416.330
Accessories:	For all accessories and details, please visit our website at www.swan.ch .	
	Swansensor pH	A-87.1X0.200
	Swansensor Redox	A-87.4XX.200
	Swansensor Ammonium, Nitrate or Fluoride (requires Swansensor Reference FL)	A-87.7X0.010
	Swansensor Reference FL	A-87.860.100
	Swansensor Pt1000 PG13.5	A-87.030.200
	Swansensor NT5K PG13.5	A-87.020.200
	Spray nozzle for sensor cleaning	A-83.491.120
	PVC panel (280 mm × 280 mm)	A-89.410.210

