

AMI Silica

Changing of AMI Silica Photometer

The AMI Silica monitor with the serial number S/N: 803 and higher are now equipped with the photometer version 2-A.

The photometer version 2-A has a different fluidic set-up from the photometer version 1-A. The photometer version 1-A uses air to transfer the reagents into the photometer, whereas the photometer version 2-A uses the sample from the photometer to transfer the reagents into the photometer.

Please contact support@swan.ch for more information.

Photometer Version 1-A	Photometer Version 2-A
	
Article number: A-87.531.300	Article number: A-87.531.310
Required firmwares <ul style="list-style-type: none"> - V5.32 or lower - PIC RoValve V1.50 - PIC Peri V1.06 	Required firmwares <ul style="list-style-type: none"> - V5.40 or higher - PIC RoValve V1.60 - PIC Peri V1.06