



AMI pH/Redox M-Flow
& AMI pH/Redox

Swansensors for a Wide Range of Swan Devices

The Swansensor pH AY and Redox AY can be used with the following instruments:



Transmitter
AMI pH/mV:pH/mV



Transmitter
AMI pH/Redox/
Temperature



AMU pH/Redox

SENSORS

Swansensor pH AY and Redox (ORP) AY

Maintenance-free sensors with poisoning protected reference systems, solid electrolyte and well protected diaphragm around the sensing tip. The diaphragm is insensitive to mechanical stress.

The sensors are equipped with an integrated temperature measurement and a 1m cable allowing the user to measure samples comfortably.

The robust and long-living pH sensor is suitable for measurements in heavily polluted samples. It is easy to operate, fast and economical to use.

Measuring Range

pH Range: pH 1-13

Redox Potential (ORP): -400 – +1200 mV



Swan Analytical Instruments · CH-8340 Hinwil
www.swaninstruments.ch · swan@swan.ch

SWISS  MADE

